SHOE DOUBLE STRETCHER Model Compact



Operator Manual



800 rue Rossiter, Saint-Jean-sur-Richelieu (QC) Canada J3B 8J1 www.landisinternational.ca info@landisinternational.ca T.(450)359-8800 TF. 1-800-634-0806 F. (450) 359-9619



DOUBLE STRETCHER

INSTRUCTION FOR ULTRACAM STRETCHER

1. Included with your new stretching machine are all the necessary lasts that you need.

1 pair men's lastsD-4 and S-4 1 pair ladie's lasts D-3 and S-3 1 pair child's lasts D-2 and S-2 1 pair baby's lasts D-1 and S-1








2. Most of the Bunion blocks have a pin on them, which plugs into the lasts at various points, according to how you want to stretch the shoe.



3. Two pairs of blocks have rivet type pin on them, which hooks into the bottom of the larger size last. This is for toe raise.





THE PRESSURE IS APPLIED USING HANDLE B.

4. One pair of blocks have a rectangular shape pin which plugs into the top of the larger last for stretching the vamp. One pair of blocks have no attaching pin which allow you to place them higher or lower in the vamp.





THE PRESSURE IS APPLIED USING HANDLE A.

5. There are also two pairs of "U" shaped hooks which are placed onto the back of the last. This will prevent the last from stretching the width of the shoe, if desired. Only stretching the front part of the shoe.







6. The 2 front handles are stretching the width. The 2 back handles are stretching the length.



7. Stretching:

- A. Choose the proper lasts for the shape and the size of the shoes or boots you work on.
- B. Stretch the length of the shoe with the back handle. The shoe must be on traction.
- C. Turn the front handle to stretch the shoe and leave on traction till the shoe stretch spray become dry. Minimum of 6 to 12 hours.

N.B. For better results, you must use shoe stretch spray.